





Robison-Anton		
Rayon		
1		2321
2		2229
3		2529
4		2437
5		2206
6		2216

Please read the following instructions carefully.

- 1. The use of non-woven, tight-knit fabric is recommended.
- 2. To ensure the best quality sewout, the use of a cutaway stabilizer backing is recommended.
- 3. The overall contrast of the design may be modified by using threads of different weights.

