



Robison-Anton		
Rayon		
1		2319
5		2414
7		2296



Please read the following instructions carefully.

- 1. The use of non-woven, tight-knit fabric is recommended.
- 2. To ensure the best quality sewout, the use of a cutaway stabilizer backing is recommended.
- 3. The overall contrast of the design may be modified by using threads of different weights.

